



## **Lancer 5% Handling Instructions**

1. At a minimum always wear chemical resistant goggles and gloves when dispensing Lancer 5% (PAA).
2. Preferred Personal Protective Equipment to wear is chemical resistant gloves, pants and coat with chemical resistant goggles under a full face shield attached to a chemical resistant hardhat.
3. Unscrew 1 ½” shipping plug from pail or tote with supplied shipping plug removal tool attached to the wall mount dispensing Unit or mobile cart dispensing unit. Save shipping plug to reinstall in the pail when empty.
4. Insert the gray threaded part of the coupler attached to the suction side of the dispensing unit’s pump and turn gray threaded part by hand clockwise until it bottoms out.
5. Do not contaminate the top of the pail or tote. Keep the pail or tote sanitary at all times. Contamination with soil, grease, oil, metal and other components is un-acceptable.
6. Always make certain that no contaminants are on the shipping plug or on top of the pail or tote when reinserting shipping plug. This can allow contamination of the product, heat generation, high pressure loss of product and potential bodily injury.
7. If leaks are present in the pail or tote and or the dispensing unit shut off the gas supply or power switch, secure the equipment in a contained area and call Heritage Systems for service. Do not attempt to repair or use equipment that is in need of repair.
8. Follow all handling, safety and precautionary instructions on the Lancer label located on the pail or tote.

Heritage Systems Inc. 2471 Solano Ave Suite 141 Napa, CA. 94558 707-258-0553  
[www.heritagesystemsinc.com](http://www.heritagesystemsinc.com)